



223 West Hampton Avenue
Capitol Heights, MD 20743
TEL (301) 336-9300
FAX (301) 336-6597
www.arcalchem.com

WELD-O

DESCRIPTION

Weld-O is a ready-to-use, x-ray quality welding prep for aluminum and all grades of alloys, with an innovative chemical formulation that consists of a blend of mineral acids, a minimum of solvent degreaser, surfactant and sequestering agents. **Weld-O** deoxidizes the surface instantly and conditions it for X-ray quality welding. As a result, the weldment is cleaner and stronger. Using **Weld-O** eliminates the need for wire brushes and other time consuming procedures. Water rinsing is seldom required.

SAFETY

This product contains hydrofluoric acid. Avoid contact with skin. Wear adequate protective rubber clothing, goggles, etc., when using this product. See SDS for further information.

APPLICATION INSTRUCTIONS

Do not dilute. Using an applicator brush with plastic bristles, apply **Weld-O** to both sides of the area being welded. This assures maximum seamliness and eliminates migration and fusion of contaminants during welding. Leave **Weld-O** on for approximately 60 seconds or until a uniform foam blanket is noticed on the surface. Wipe the area with a clean sponge or cloth. The surface is now prepped for welding and insures a stronger and cleaner weld.

PACKAGING

- Quart bottles (Case of 12).
- 5-gallon pail
- 55-gallon drum

SHELF LIFE

5 years when stored in a closed container.

This information is believed to be authentic and correct as determined by laboratory and field-testing. No warranty or guaranteed results are implied or intended due to application circumstances and usage beyond the control of the seller and manufacturer.